



INSTRUCTION MANUAL



WASHING MACHINES

CI230

CI330

WASHER DRYERS

CI830

CI930

Thank you

for purchasing this **|C|D|A|** product

which comes to you with a 5 year guarantee*

Please don't forget to **REGISTER THIS APPLIANCE WITHIN 30 DAYS**

by completing the Registration of Purchase Card enclosed.

Having bought your new appliance, it is important to register the purchase.

This ensures you receive prompt and efficient service in the event that the product requires attention during its guarantee period.

If you have any queries please contact us in one of the following ways:

T : 01949 862 012

F : 01949 862 003

E : service@cda.eu

* Terms and Conditions available upon request.

washing machine

contents

WARNINGS	4
SPECIFICATIONS	5
INSTALLATION AND ASSEMBLY	6
USING THE APPLIANCE. PRACTICAL TIPS	10
MAINTENANCE AND CLEANING	19
SAFETY AND TROUBLESHOOTING	21
ENVIRONMENTAL WARNINGS	24


warnings

To avoid the risk of fire, electric shocks, injury or damage when using your washing machine, please take the following precautions:


- This washing machine comes with a manual that includes operating, maintenance and installation instructions. Please read all the instructions before using the washing machine.
- Do not wash items that have previously been cleaned, washed, soaked or treated with petrol, solvents for dry cleaning, other inflammable substances or explosives, as they produce fumes that could catch fire or explode.
- Do not add petrol, solvents for dry cleaning or other inflammable or explosive substances to the wash water as they produce fumes that could catch fire or explode.
- Do not repair or replace any part of the washing machine or try to carry out any type of servicing unless it is recommended in the maintenance instructions in the manual.
- Do not climb onto the machine or stand on the open hatch door.
- Do not use an extension lead or adaptor to connect your washing machine to the mains supply.
- The machine should only be used for the purpose it is designed for.
- Follow the washing instructions recommended by the manufacturer of the garment to be washed.
- Do not turn your washing machine on until you are sure that:
 - It has been installed in accordance with the installation instructions.
 - All the water, drainage, mains electricity and earth connections meet the local regulations and/or other applicable regulations.

washing machine

specifications



ACCESSORIES



Water inlet hose.


washing machine

installation and assembly

1 UNPACKING AND UNBLOCKING THE WASHING MACHINE




UNPACKING

- a** Remove the base, corner protectors and top cover.



UNBLOCKING

- a** Remove the screws holding the plastic covers to the back of the washing machine.
- b** Loosen and remove the 3 blocking screws.
- c** Cover the holes with the plastic covers you have just removed.



Important

Do not throw the blocking screws away. You may need to move the washing machine at a later date.



2 CONNECTION TO THE MAINS WATER SUPPLY AND DRAINAGE

installation and assembly

CONNECTION TO THE MAINS WATER SUPPLY

The water supply hose is inside the drum:


- a** Connect the bent end of the hose to the threaded inlet of the electrovalve located at the rear of the washing machine.
- b** Connect the other end of the hose to the water intake. Then securely tighten the connection nut.



It is important that the drain hose bend is correctly fastened to the outlet, to prevent any risk of it becoming detached and causing flooding.


If your washing machine has a hot water intake, connect the hose with the red threaded end to the hot water tap, and to the electrovalve with the red filter.

The washing machine must be connected to the mains water supply, using the new supply hoses supplied with the appliance. Do not use water supply hoses that have been used before. For your washing machine to work properly, the mains water pressure must be between 0.05 and 1MPa (0.05 and 10 Kgr/cm²).



DRAINAGE CONNECTION

- a** It is recommended that you have a fixed drainage outlet 50 to 70 cm from the floor. Avoid the drain hose being too tight, kinked or restricted.



Important

3 LEVELLING THE WASHING MACHINE AND CONNECTING IT TO THE MAINS ELECTRICITY SUPPLY

installation and assembly




LEVELLING

Important

Use the adjustable feet to level the washing machine. This will reduce the noise level and prevent it from moving during use.

Do not bring the feet too far out, you will achieve better stability.


You need to use a spanner for the models that have a nut.



ELECTRICAL CONNECTION

Consult the specifications plate located on the hatch door of the washing machine before making the electrical connections. Ensure that the voltage reaching the plug is the same as that on the plate.

Do not remove the specifications plate. The information on it is important.



Important

It is very important to correctly earth the washing machine. The electrical installation, plug, socket, fuses or automatic switch and counter must be correctly dimensioned for the maximum power indicated on the specifications plate.

Do not plug the washing machine plug into the socket with wet or damp hands.

To remove the power cord, pull on the body of the plug.

If the power cord is damaged, it must be replaced by a cord or special unit provided by either the manufacturer or your after-sales service.

With built-in washing machines, the plug must be accessible after installation.

4 INSTALLING THE WASHING MACHINE UNDER A KITCHEN WORKTOP AND PRE-CLEANING



INSTALLATION UNDER A WORKTOP

Your washing machine may be fitted underneath a kitchen worktop.

If you need to remove the washing machine's worktop, for safety reasons you need to fit a protection plate which you can obtain from your Dealer or CDA Customer Care.

Follow these steps to fit the plate:

- a** Remove the washing machine work top by taking out the side screws and moving it gently back.
- b** Take out the screws and remove the parts holding the worktop in place.
- c** Put the protection plate into place and screw it to the washing machine so it can then be inserted in the place you wish, fitting spongy adhesive all around the perimeter first to prevent noise.




PRE-CLEANING

When your washing machine has been correctly installed, we recommend that you pre-clean the machine.

This is to check that the installation, the connections and the drainage are all correct, and to thoroughly clean the inside of the washing machine before any wash programmes are run (see the operating instructions on the following pages).

- a** Select the normal programme at 60°C.
- b** Press the start/pause button.



washing machine

using the appliance and practical tips


1 PREPARING GARMENTS FOR WASHING

PREPARATION

Important

Before placing the clothes in the drum, make sure all the pockets are empty.

Any small objects may block the drain pump.



SORTING THE CLOTHES

a Sort the clothes according to fabric and how they are made:

We recommend using the delicate programmes for sensitive fabrics. There is a special wool programme for woollens.

b Sort clothes according to how soiled they are.

- Wash lightly soiled garments using a short programme.
- Use a programme without prewash for medium-soiled garments.
- Wash heavily soiled garments using a long programme with prewash.

a Sort your clothes according to colour.


Wash whites and coloured separately.

Important

We recommend loading the washing machine to its full capacity. This means savings on water and energy.



Whenever possible, we recommend that you wash garments of different sizes within the same wash programme. This improves the washing action and also aids the correct distribution of the garments in the drum when spin-drying, and the washing machine will therefore be quieter.

It is a good idea to put small garments in a wash bag.



Important

Make sure beforehand that your woollens can be machine-washed.



2 USING DETERGENT AND ADDITIVES

using the appliance and practical tips

DETERGENT AND ADDITIVES

- a** Your washing machine's detergent dispenser has three compartments.
- b** Put the detergent or additive into the detergent dispenser before starting the wash programme.
- c** Liquid detergents may also be used in this washing machine.

Important




The level of liquid must never be higher than the MAX mark printed on the dispenser wall.

Remember that the amount of detergent to be used will always depend on:

- The amount of clothes to be washed.
- How heavily the clothes are soiled.
- The hardness of the water (Information on water hardness in your area can be obtained from the local authorities).

Important

We recommend the use of a decalcifying product if the water hardness is high in your area.



eco-note

Remember that concentrated detergents exist which are more environment- and nature-friendly.

The use of more detergent than necessary will not improve your washing results, and apart from costing




you money it will have a negative effect on the preservation of the environment.

We therefore recommend you follow the detergent manufacturer's instructions.

3 SELECTING THE WASH PROGRAMME




using the appliance and practical tips



using the appliance and practical tips

To select a wash programme, proceed as follows:

- a** Select the wash programme by turning the programme selector (see programme table).
- b** In the command carrier the End of Programme pilot light flashes on and off.
- c** Press the start/pause button.



There are four types of programme:

Normal programmes
Auxiliary programmes
Wool programmes
Delicate programmes

PROGRAMMES			
Normal	Auxiliary	Wool	Delicate
1 Quick 30°C	8 Rinses	10 Wool 35°C	12 Delicate 60°C
2 Normal cold	9 Spin-drying	11 Wool cold	13 Delicate 40°C
3 Normal 30°C			14 Delicate 30°C
4 Normal 40°C			15 Delicate cold
5 Normal 60°C			
6 Normal 90°C			
7 Prewash 60°C			

eco-note

We recommend you choose a wash programme without prewash whenever possible. This will save you money and help protect the environment.



Programme		Recommended temperature	Fabric type	Possible option buttons						
				Extra rinse	Intensive wash	Easy- iron	Spin speed selection	No spin	Anti-crease	
Normal programmes	1	Quick 30°C		Cotton/Linen whites/colours very light soil	YES	NO	YES			
	2	Normal cold	Cold	Cotton/Linen delicate colours very light soil	YES					
	3	Normal 30°C		Cotton/Linen delicate colours light soil	YES					
	4	Normal 40°C		Cotton/Linen fast colours light soil	YES					
	5 (*)	Normal 60°C		Cotton/Linen fast colours medium soil	YES					
	6	Normal 90°C		Cotton/Linen whites heavy soil	YES					
	7	Prewash 60°C		Cotton/Linen whites/fast colours heavy soil	YES					
Auxiliary prog.	8	Rinses	—	Cotton/cotton mix Synthetic/Delicate Wool/wool mix	YES	NO	YES			
	9	Spin-drying	—	Cotton/cotton mix Synthetic/Delicate Wool/wool mix	NO		YES		NO	
Wool prog.	10	Wool 35°C	WOOL 35	Wool/wool mix whites/colours light soil	YES	NO	YES			
	11	Wool cold	Wool cold	Wool/wool mix whites/colours very light soil	YES	NO	YES			
Delicate programmes	12	Delicate 60°C		Synthetic/cotton mix whites/fast colours medium soil	YES					
	13	Delicate 40°C		Synthetic/cotton mix delicate colours medium soil	YES					
	14	Delicate 30°C		Synthetic/cotton mix delicate colours light soil	YES					
	15	Delicate cold	Cold	Synthetic/cotton mix delicate colours very light soil	YES					

(*) Programme for wash and energy consumption assessment in accordance with standard EN60456, press intensive wash button.

Max load of clothes (Kg)	Wash product compartment	Programme description	Total consumption kWh/litres		Approx. duration (minutes)
			5 Kg	6 Kg	
1.5		SHORT wash, rinses, fabric conditioner if desired and long final spin	0,20/25	0,20/30	30
5/6		Normal wash, rinses, fabric conditioner if desired and long final spin	0,15/46	0,15/49	60
5/6		Normal wash, rinses, fabric conditioner if desired and long final spin	0,35/46	0,40/49	82
5/6			0,60/46	0,65/49	87
5/6			0,95/46	1,02/49	91
5/6			1,60/51	1,90/55	120
5/6		Prewash, normal wash, rinses, fabric conditioner if desired and long final spin	1,40/55	1,45/60	105
5/6		Rinses, fabric conditioner if desired and long final spin	0,05/25	0,05/30	23
5/6	—	Drain and long final spin	0,05/0	0,05/0	10
1		WOOL wash, rinses, fabric conditioner if desired and gentle final spin	0,45/60	0,50/60	40
1			0,05/60	0,05/60	30
3		Delicate wash, rinses, fabric conditioner if desired and gentle final spin	0,95/50	1,00/55	70
3			0,55/50	0,60/55	60
3			0,35/50	0,35/55	55
3			0,15/50	0,15/55	55

NOTE: the kWh and litre consumptions and programme durations may vary depending on the type and amount of clothes, mains water pressure, etc.

4 SELECTING THE ADDITIONAL FUNCTIONS


using the appliance and practical tips

SPIN-DRYING

The selected programme is associated with spin-drying revolutions.

a It can be changed by turning the spin-drying selector command.

b **Elimination of spin-drying 0**
By turning the spin-drying selector command we come to the spin-drying elimination command. A programme without final spin-drying; it is used for avoiding the formation of creases in special fabrics.




STOP/ANTI-CREASE

The washing process stops with the last rinsing; the clothes remain with water.


To end the programme, select the desired spin-drying speed and press the Operation/Pause key.

It is used, for example, when you are not at home and want to delay the spin-drying until you get home, to prevent the clothes creasing after spin-drying and being left in the drum to be removed.



INTENSIVE WASH


This option, specially recommended for heavily soiled, stained clothes, achieves better results by extending the normal wash cycle.



using the appliance and practical tips


EASY IRONING

This option avoids the formation of creases in the garments by the operation of a special programme with special turns to soften the clothes after the spin so as to make ironing easier.



EXTRA RINSE


Increases the level of the final rinse obtained in the clothes; suitable for large loads and garments belonging to people with sensitive skin. Increases water consumption!



DELAY START

The delay should be selected after choosing the washing programme.


To select the delay hours, turn the delay start control, choosing between 1, 3, 6, 9, 12, 15 and 19 hours delay. In the delay position, the three washing phase pilot lights will be flashing alternately left and right.



STARTING UP

Start/pause button

a To start up the washing machine you have to press the **start/pause button**.



5 WASH PROGRAMME PHASES AND POWER CUTS

using the appliance and practical tips

PROGRAMME PHASES

When the programme is running, the phase the programme is at will appear on the display together.

The active phases will appear successively as the programme progresses: the wash, rinse and end.

Any option button can be selected provided the wash phase in which it takes effect has not been passed and when the programme accepts the option.

Pressing the start/pause button during the wash activates the PAUSE function.



Important

If you change the wash programme during the wash using the selector, the PAUSE function is activated and the programme is cancelled.

If you need to add or remove a garment, press the start/pause button and make sure that the water level is not above the door overflow level and that the temperature inside is not high. Press the start/pause button again to restart the wash from the same cycle phase it had stopped at.

POWER CUTS

If there is a power cut, when the electricity comes back on the washing machine will continue to run from where it left off (it has several hours of memory). The same will happen if the ON/OFF button is pressed.

warnings

■ Level the washing machine by adjusting the feet to reduce the noise caused by spin-drying.

■ Try and wash clothes of different sizes in the same wash programme to favour the distribution of the clothes inside the drum during spin-drying.

■ All the models have a safety system for spin-drying that prevents spin-drying from being carried out if the distribution of the clothes inside the drum is too concentrated. This prevents the appliance from vibrating too much.

If you find that the clothes are not properly wrung out, try spin-drying them again after having distributed the clothes more evenly in the drum.

washing machine

maintenance and cleaning


MAINTENANCE

After each wash, leave the door open for a while to allow the air to circulate freely inside the machine.

From time to time, depending on the hardness of your water, it is recommendable to run a full wash cycle using a decalcifying product. **This will extend the life of your washing machine.**

Important

The washing machine should be disconnected from the mains electricity supply before any cleaning or maintenance is carried out.






1 CLEANING THE DETERGENT DISPENSER

Clean the detergent dispenser whenever there is any washing product residue left inside.

- a** Pull outwards on the detergent dispenser to remove it completely.
- b** Use warm water and a brush to clean the compartments.
- c** Also clean the additive compartment siphons, having removed them first. Once they have been cleaned, put them back making sure that they fit right in to the back. Put the dispenser back into the washing machine.

Important

A dirty or incorrectly fitted siphon will prevent the additives from being taken in and leave water inside the compartment at the end of the wash.




2 CLEANING THE ACCESSIBLE FILTER AND THE OUTSIDE

maintenance and cleaning

CLEANING THE FILTER

Clean the accessible filter if the drain pump is blocked by any foreign objects.

- a** Remove the kickplate by pulling gently on its edges and turning it downwards, to release the clips. If you do not have access from the side, insert a small screwdriver into the three slots at the top of the kickplate, in order to get leverage and release the clips.
- b** Place a container under the drain pump filter to collect any water that comes out of it.
- c** Half- or quarter-turn the filter to the left. Water will start to come out.
- d** When all the water has drained out of the washing machine, turn the filter several times until it can be completely removed by gently pulling on it.
- e** Remove the objects or fluff caught in the filter or the drain pump.
- f** Put the filter and kickplate back in place again.



Important

To avoid burns, do not carry out this operation when the wash water is at a temperature of over 30°C.

CLEANING THE OUTSIDE

The outside of the washing machine should be cleaned with warm soapy water or a gentle cleaning agent. Do not use abrasive cleaning products or solvents. It should then be thoroughly dried with a soft cloth.

Important

When there have been spillages of detergent or additives from the dispenser onto the washing machine cabinet, clean them up right away as they are corrosive.

washing machine

safety and troubleshooting

Important

Never open up the appliance. There is no fuse or similar component inside that can be replaced by the user.

If you detect any problems with your washing machine, you will probably be able to rectify them yourself by consulting the following instructions.

If this is not the case, unplug the appliance and contact **CDA CUSTOMER CARE**.

Problems	Indicator mod. with a screen	Indicator mod. without a screen
No water coming in	F01	the wash and rinse pilot lights will flash alternately
Does not drain or spin-dry	F02	the rinse and end pilot lights will flash alternately
Does not spin-dry	CO3	the wash, rinse and end pilot lights will flash alternately while all the other control panel pilot lights will remain off
Does not start	F04	the wash and end pilot lights will flash alternately
Call CDA Customer Care	F05	the wash, rinse and end pilot lights will flash, together with one of the other control panel pilot lights
	:	
	:	
	F10	

PROBLEMS

Why won't the washing machine start?

This may be due to the following:

- Check the door is properly shut.
- The washing machine is not plugged into the mains or there is no voltage in the mains supply.
- The Start/Pause button has not been pressed.

If the washing machine door is not properly shut, **F04** will appear on the display or the wash and end pilot lights will flash alternately.

Why is the washing machine vibrating or making too much noise?

This may be due to the following:

- The blocking and transport screws have not been removed.
- The washing machine has not been correctly levelled.

Why doesn't the washing machine take in water?

■ Indicator **F01**, no water coming in, this may be due to a cut in the water supply, a tap turned off or a blocked water inlet filter.

■ The possible solutions are as follows: wait for the water supply to be reconnected, turn on the tap, or remove the water inlet hose and clean the filter.

If this failure is detected, **F01** will appear on the display or the wash and rinse pilot lights will flash.

Why doesn't the washing machine drain or spin-dry?

■ The reasons for the **F02** indicator may be the following: washing machine drain pump blocked, building drainage pipes blocked, or incorrect pump electrical connection.

■ Solution: if the pump is blocked, gain access to it as described in section 2, maintaining and cleaning the appliance.

If this failure is detected, **F02** will appear on the display or the rinse and end pilot lights will flash.

Why doesn't the washing machine spin-dry?

■ This may be due to an uneven distribution of clothes in the drum and may cause an excessive level of vibrations.

■ The solution is to select a spin-drying programme.

If this failure is detected, **C3** will appear on the display or the wash, rinse and end pilot lights will flash alternately while all the other control panel pilot lights will remain off.

Why can't I see any water in the drum during the wash?

This is due to the fact that the washing machine is provided with a system which is able to adapt to the load and type of fabrics, adjusting the levels of water and energy used, in order to preserve the environment.

So, although the water level you can see through the hatch may look low, there is no cause for concern as washing and rinsing efficiency will still be optimum.

Why is there still some water in the dispenser?

This may be because the dispenser needs cleaning. This simple operation is described in **Maintaining and cleaning the appliance**.

1- Cleaning the detergent dispenser.

Why can't I open the hatch immediately after the wash has finished?

Washing machines today are provided with safety systems for users. One of them is that the washing machine cannot be opened until it is certain that the drum is quite still. This is why the hatch cannot be opened for 2 minutes.

Why doesn't the remaining time shown on the clock coincide with the real time left until the selected cycle finishes?

This time is for guidance purposes only and may be affected by the conditions under which the selected programme is being run, e.g. initial water temperature, size of load or unbalance caused by the garments during spin drying.

Other anomalies

The washing machine can detect other indications. When this happens a number of other indicators appear on the display: **F05, F06, ..., F10** or the wash, rinse and end pilot lights will flash, together with one of the other control panel pilot lights.

Check if the problem is repeated and in this case call CDA CUSTOMER CARE.

washing machine

environmental warnings

eco-note

INFORMATION FOR THE CORRECT DISPOSAL OF WASTE ELECTRICAL AND ELECTRONIC APPLIANCES

When your appliance is of no further use, it should not be disposed of together with general domestic waste.

It can be taken, free of charge, to a specific waste collection centre, run by your local authority, or dealers who provide this service.

Disposing of waste domestic appliances separately means avoiding possible negative consequences for the environment and health, derived from incorrect disposal. This will enable the materials in them to be treated and recycled, obtaining important savings in energy and resources.

To highlight the obligation of collaborating with selective waste collection, the product is marked with a symbol to warn against using traditional containers for disposing of the appliance.



For further information, contact your local authority or the shop where you purchased the product.





The |C|D|A| Group Ltd

A : Harby Road • Langar • Nottingham • NG13 9HY • UK

T : 01949 862 012 • **F** : 01949 862 003

E : service@cda.eu • **W** : www.cda.eu